



ご質問がございましたら SEA EAGLE, Japan (日本正規代理店) までメールでご連絡下さい。
<https://www.seaeagle.jp/en/contact-us>

Frameless Pontoon 285 Fishing Boat

この度は SEA EAGLE の高品質インフレーターブルフィッシングボートをお買い上げ頂き誠にありがとうございます。

組み立て・収納方法:

1. リペアキットからバルブアダプターを取り出し、ポンプホースに装着してください。
2. ボートを広げる。バルブキャップを外して下さい。バルブステム（バルブ軸）を押しながら左へ 1/4 バルブステムが立ち上がるまで回して下さい。
3. バルブ開口部にバルブアダプターを差し込み右に回して固定して下さい。
4. フロアボードとモーターマウントをお持ちの場合はエアチューブを半分膨らませてからフラアボード、アチューブを装着してください。
5. エアチューブを完全に膨らませてください。目安としてはシワが伸び強く感じられる程度です。
6. 完全にボートを膨らませたら、全てのバルブキャップを閉じてください。
7. Deluxe Fishing Seat (デラックス フィッシングシート) を膨らませるには黒いバルブが必要です。リングをバルブベースに付けて、バルブベースにバルブを取り付けて下さい。トリプルバルブアダプターのうねのある端をポンプホースに挿入し、好みの硬さになるまで空気を入れてください。
8. オール: シャフトを組み立ててください、オールに開いている穴をオールロックに挿しナットとマジックテープで固定します。
9. ボートの収納: バルブキャップを取り外し、バルブステムを押しながら 1/4 右へ回すとバルブステムの弁が下がり空気が素早く出てきます。フロアボードとモーターマウントを外します。(プロパッケージの場合) バルブの方へボートを折り畳んでください。十分に乾燥させてから収納してください。
10. シートの空気を抜きます。バルブを回しながら緩めてください。

* 付属のアクセサリーについては一度ビデオを見て下さい。

ご使用上の注意:

- 作動圧力: 3.2 PSI (22 kPa) / DK Seats: 1 PSI (7 kPa)
- SEA EAGLE 推奨のポンプを使用してください。市販のエアコンプレッサーは絶対に使用しないでください。(CO₂または空気)
- 現地の河川・海上航行ルール、その他、規制・規則・法律を順守しましょう。
- ボート、カヤックに乗る際は必ずライフジャケットを着用しましょう。
- 絶対に子どもだけで SEA EAGLE ボート・カヤックを使用しないでください。
- 飲酒または薬を服用した後はカヤックを操縦しないでください。操船中にアルコールを摂取しないでください。
- 砂利や岩場の上などで SEA EAGLE ボート・カヤックを引きずらないようにしてください。可能であれば持ち上げて運んで下さい。
- ボートの最大積載量、定員を超えて乗船しないでください。最大積載量はボート内側に記載しています。
- 1人でカヤック、ポーティングに行かないでください。特にキャンプ、海旅や急流下りをする場合。
- 本製品は救命具ではありません。SEA EAGLE ボート・カヤックを絶対に救命具として使用しないで下さい。
- 水上に行く時は、常に誰かに何処に誰と行くか帰宅の予定は何時になるかを伝えて下さい。
- 全ての ボート・カヤックはメーカーの欠陥に対する3年間の保証があります(詳しくはオンラインでご確認ください。)

SEA EAGLE 製品をご利用になる前に www.seaeagle.jp/ja/se/cat/5-Instructions で取扱説明ビデオをご覧ください。



Questions: Email Customer Service at <https://www.seaeagle.jp/en/contact-us>

Frameless Pontoon 285 Fishing Boat

Thank you for your purchase of our high quality inflatable fishing boat.

Basic Inflation Instructions:

1. Take the valve adapter from the repair kit and attach it to pump hose.
 2. Roll out boat. Remove valve caps. Press and turn the valve stem a ¼ turn to the left until it pops up.
 3. Insert valve adapter into valve opening, turn right to lock in place.
 4. If you have the floorboard and motor mount, inflate pontoon sides to 1/2 full so they can be installed.
 5. Fully inflate side pontoons until pumping becomes difficult (Pontoons should be wrinkle-free)
 6. Close valve caps after inflating the boat.
 7. For the Inflatable Fishing Seat, locate the black valves. Attach the ring to the base then screw the valve in the valve base. Insert the ribbed end of the triple valve adapter in the pump hose. Pump until comfortable.
 8. Oar assembly: Snap the 2 shafts of each oar together. Put in oarlocks and secure with retaining nuts and Velcro.
 9. Deflate boat by removing valve cap, push stem down and turn stem a ¼ turn to the right until it stays down. Remove floorboards and motor mount (if you have the Pro Package); Fold boat toward valves. Wipe dry before storing.
 10. Deflate seats by unscrewing the valves.
- * See the Instructional video for the one-time assembly requirements

Other Points:

- Working pressure of the pontoons: 3.2 PSI / DK Seats: 1 PSI
- Only use Sea Eagle recommended pumps and NEVER an air compressor (CO2 or air)
- Be aware of local boating rules and regulations and abide by them accordingly.
- Always wear a life jacket when on the water.
- DO NOT allow children to use Sea Eagle boats unsupervised.
- DO NOT consume alcohol while boating or operating a boat while under the influence of alcohol or drugs.
- DO NOT drag your Sea Eagle boat over rocks or gravel if it can be avoided.
- DO NOT exceed the certified maximum weight capacities of this boat – see capacity label on the inside of kayak.
- DO NOT go boating alone, especially if camping, exploring or going down a white water river.
- DO NOT use your Sea Eagle Boat as a personal flotation device as they are not designed for that use.
- Always let someone know where you are going and when you plan to return.
- All Sea Eagle boats have a limited 3 year Warranty against manufacturer's defects (more detail online)

Make sure to watch the instructional video at:

www.seaeagle.jp/ja/se/cat/5-Instructions before using your Sea Eagle.