



ご質問がございましたら SEA EAGLE, Japan（日本正規代理店）までメールでご連絡下さい。
<https://www.seaeagle.jp/en/contact-us>

NeedleNose™ SUP 116/126/14

この度は SEA EAGLE の高品質インフレーターブル SUP をお買い上げ頂き誠にありがとうございます。

組み立て・収納方法:

1. 高圧ハンドポンプのハンドルに圧力計を取り付けます。圧力計にホースを接続して下さい。
2. SUP を広げる。バルブキャップを外して下さい。バルブステム（バルブ軸）を押しながら左へ 1/4 バルブステムが立ち上がるまで回して下さい。
3. バルブ開口部にバルブアダプターを差し込み右に回して固定して下さい。
4. SUP を 12~15 PSI (83~103 kPa) まで膨らませてください。
5. SUP を膨らませ終えたら、バルブキャップを閉じてください。
6. SUP パドル: シャフトを組み立てハンドルを中に入れてください。スナップをとめて下さい。
7. カヤックパドル (Deluxe パッケージ) の組み立て: シャフトの端にドリップガードを挿入し、3 つの穴が中央に来るようにシャフトを組み立ててください。
8. SUP の収納: バルブキャップを取り外し、バルブステムを押しながら 1/4 右へ回すとバルブステムが弁が下がり空気が素早く出てきます。空気を抜くときは空気バルブに目や顔や物を近づけないでください。
9. NeedleNose™ SUP のコーンを横に折りたたんでください。それから前から後ろに折りたたんでください。スケグベースを曲げないように注意してください。十分に乾燥させてから収納してください。

ご使用上の注意:

- 作動圧力: NeedleNose™ SUP 12~15 PSI (83~103 kPa) / Deluxe Kayak Seat (DKS)（デラックス カヤックシート）1 PSI (7 kPa)。
- SEA EAGLE 推奨のポンプを使用してください。市販のエアコンプレッサーは絶対に使用しないでください。（CO₂ または空気）
- 現地の河川・海上航行ルール、その他、規制・規則・法律を順守しましょう。
- 水上に出る際は、ライフジャケットを持参しましょう。
- 絶対に子どもだけで SEA EAGLE ボート・カヤック・SUP を使用しないでください。
- 飲酒または薬を服用した後は SUP に乗らないでください。アルコールを摂取しながらパドルボーディングしないでください。
- 砂利や岩場の上などで SEA EAGLE ボート・カヤック・SUP を引きずらないようにしてください。可能であれば持ち上げて運んで下さい。
- NeedleNose™ SUP シリーズの最大積載量: (NN116 91 kg / NN126 102 kg / NN14 125 kg)
SUP の最大積載量、定員を超えて乗船しないでください。
- 1 人でパドルボーディングに行かないでください。特にキャンプ、海旅や急流下りをする場合。
- 本製品は救命具ではありません。SEA EAGLE ボート・カヤック・SUP を絶対に救命具として使用しないで下さい。
- 水上に行く時は、常に誰かに何処に誰と行くか帰宅の予定は何時になるかを伝えて下さい。
- 全ての ボート・カヤック・SUP はメーカーの欠陥に対する 3 年間の保証があります（詳しくはオンラインでご確認ください。）

SEA EAGLE 製品をご利用になる前に www.seaeagle.jp/ja/se/cat/5-Instructions
で取扱説明ビデオをご覧ください。



Questions: Email Customer Service at <https://www.seaeagle.jp/en/contact-us>

NeedleNose™ SUP 116/126/14

Thank you for your purchase of our high quality inflatable SUP.

Basic Inflation Instructions:

1. Connect the inline pressure gauge to the handle of the High Pressure hand Pump. Connect the hose to the pressure gauge.
2. Roll out SUP. Remove valve cap. Press and turn the valve stem a ¼ turn to the left until it pops up.
3. Insert valve adapter into valve opening, turn right to lock in place.
4. Inflate the SUP to 12~15 PSI.
5. Close valve cap after inflating.
6. Assemble the 3-part SUP paddle by snapping in the lower part and sliding in the handle.
7. Kayak Paddle assembly (Deluxe Package): Insert the drip guards on the end of the paddle shaft. Assemble shaft with the three holes in the middle.
8. Deflate SUP by removing valve cap, push stem down and turn stem right until it stays down. KEEP FACE AWAY FROM AIR AS IT RELEASES.
9. Fold the Needle Nose cone across the board. Then roll it from nose to tail. Skeg base must be kept flat. Wipe dry before storing.

Other Points:

- Working pressure of the NeedleNose SUP: 12~15 PSI / DK Seats: 1 PSI.
- Only use Sea Eagle recommended pumps and NEVER an air compressor (CO2 or air).
- Be aware of local boating rules and regulations and abide by them accordingly.
- Always have a life jacket with you when on the water.
- DO NOT allow children to use Sea Eagle boats/SUPs unsupervised.
- DO NOT consume or be under the influence of alcohol or drugs while paddle boarding.
- DO NOT drag your Sea Eagle SUP over rocks or gravel if it can be avoided.
- DO NOT exceed the maximum prescribed weight capacity for this SUP – 91 kg for NN116, 102 kg for NN126 & 125 kg for NN14.
- DO NOT go paddle boarding alone, especially if camping, exploring, or ocean surfing.
- DO NOT use your Sea Eagle SUP as a personal flotation device as they are not designed for that use.
- Always let someone know where you are going and when you plan to return.
- All Sea Eagle boats and boards have a limited 3 year Warranty against manufacturer's defects (more detail online).

Make sure to watch the instructional video at:

www.seaeagle.jp/ja/se/cat/5-Instructions before using your Sea Eagle.